




Biogas Monitoring – Technologies, Challenges, Solutions
Jan Talkenberger, Manager International Sales, Binder GmbH

BINDER


■ Introduction

- Binder's core business is Gas Flow Metering and Control.
- Aeration Control System & Digester Gas Flow Metering & Gas Analysis

Real Gas Flow Calibration



Gas Flow Conditioning



Gas Flow Measurement



Gas Flow Control



BINDER

Binder Group AG Finance Holding



Binder Engineering GmbH Sales & Service Companies in DE / F / CH / NL / B / China, Singapore, Malaysia



BINDER GmbH Manufacturing Company for Gas Flowmeter, Gas Analyzer and Control Systems
with following products: **COMBIMASS® / VACOMASS® / CAMASS®**



INSTRUM AG Manufacturing Company for Stainless Steel Pressure Regulators and Valves



BETA B.V. Manufacturing Company for Pressure and Temperature Switches



www.bindergroup.info

BINDER

3rd NATIONAL BIOGAS CONFERENCE Midrand, South Africa, 03 Nov 2017

- Monitoring of gas quality and quantity
- Challenges and technologies
- Measurement of MJ
- Summary




BINDER

Why is it necessary to monitor Biogas Plants?



BINDER

Parameters to be monitored in a biogas plant



BINDER

Equipment used for treatment and utilization of the biogas

- H₂S scrubber
- Blowers or compressors
- Biogas engine (CHP unit)
- Biogas upgrade technology (Membrane, ...)

Typically this all are sophisticated and rather expensive devices.

BINDER

How monitoring of biogas becomes essential

- Performance of H₂S scrubbers:
 - Control operation of H₂S scrubber according to cleaning performance or oxygen values
- Control and adjustment of CHP units
 - Adjust engine parameters according to changing CH₄ concentration
- Grid injection or other further use
 - Monitor gas quality (composition) and quantity

BINDER



Example: Monitoring of H₂S concentration

- H₂S filter shall clean the gas to a suitable concentration for following equipment
- Performance of the H₂S filter depends on its principle and handling
- H₂S concentration at scrubber output must be monitored!
 - Scrubber performance check
 - **Protect the gas-using equipment, e.g. CHP engine**



BINDER

Cost - CHP engine repair vs. Gas Analyzer

CHP breakdown	Gas Analyzer
CHP repair: 20.000 – 50.000 EUR	Purchase: 8.000 – 10.000 EUR
Loss of income: 1.000 – 10.000 EUR	Installation: 1.000 EUR
	Maintenance: 1.000 EUR / year
Total: 21.000 – 60.000 EUR	Total: 10.000 – 12.000 EUR
<p>↓</p> <p>Thread: bankruptcy of plant operator</p>	<p><u>Additional benefit:</u> use measured parameter to operate the plant more efficient and economic</p>
	

BINDER

VEREIN DEUTSCHER INGENIEURE	Emissionsminderung Biologische Abfallbehandlungsanlagen – Kompostierung und Vergärung Anlagenkapazität mehr als ca. 6.000 Mg/a Emission control Biological waste treatment facilities Composting and anaerobic digestion Plant capacities more than approx. 6.000 Mg/a	VDI 3475 Blatt 1 / Part 1 Ausg. deutsch/englisch Issue German/English
-----------------------------------	---	--

„... It is **highly advisable** to analyze the composition of the biogas in the raw state and before the CHP regarding CH₄, H₂S and O₂. Thus, changes in the biogas and the cleaning measures function can be monitored. The analysis must be made regularly **at least daily**. In case of unevenly distributed feeding and expected fluctuations in the biogas composition, the analysis frequency needs to be adapted.

It is advisable to use **gas analyzer with set-limits and alarm** and opportunity to integrate them into an existing plant control. Methane sensors must be pressure and temperature compensated; hydrogen sulphide sensors also need to be sufficiently resistant with peak concentrations. **Regular calibration according to the manufacturer's instructions** are generally to follow... "

BINDER

Why is process monitoring necessary?

- **Supervision** of individual components, e.g. H₂S scrubber
- **Protection** of sensitive equipment, e.g. CHP-engine
- **Preventive alarm** settings to react timely on process fluctuations
- **Improve** feeding cycles and reduce raw material usage
- **Comply** to legal requirements, e.g. evidence of biogas production and gas-quality

→ ***Increase of safety, efficiency and profitability***





BINDER


Biogas particularities



BINDER

BIOGAS – a mixture of different gases

	<i>Gas component</i>	<i>Description</i>	<i>Challenge</i>
	CH ₄ (Methane)	The product which we want	Maximize yield
	H ₂ S (Hydrogen Sulfite)	The problem	Toxic and corrosive
	O ₂ (Oxygen)	Carefully to be watched	Avoid explosion
	CO ₂ (Carbon Dioxide)	Complementary to CH ₄	




BINDER

Gas qualities on the different measuring points

<i>Gas Production</i>	<i>Gas User</i>	<i>Gas Upgrade</i>
dirty, wet, corrosive	Less dirty, partly dry,corrosive	Clean, dry
low pressure (-3...+3 mbar)	higher pressure (40...80 mbar)	high pressure (bar ranges)
low velocities (0,5...3m/s)	higher velocity (8...15 m/s)	high velocity
CH ₄ 48-54 Vol.-%	CH ₄ 48-54 Vol.-%	CH ₄ 95-98 Vol.-%
H ₂ S up to 10000 ppm	H ₂ S < 100 ppm	H ₂ S < 2 ppm
O ₂ 0-1 Vol.-%	O ₂ 0-1 Vol.-%	O ₂ 0-1 Vol.-%
CO ₂ 38-42 Vol.-%	CO ₂ 38-42 Vol.-%	CO ₂ 2-5 Vol.-%

Definition Standard-Cubic-Meter

Measuring volumetric flow



p & T compensation necessary for:

- Orifice plates DP
- Vortex flow meter
- Turbine meters/ mechanical counters
- Ultrasonic flow meter
- Pitot tubes
- ...

BINDER

Technologies for
Flow & Analyze of
Biogas




BINDER

COMBIMASS[®] - thermal gas flow measurement



BINDER

COMBIMASS[®] Thermal dispersion mass flow measurement



Temperature:

Sensors measure resistance (by use of Pt100 sensors) – second sensor provides as reference

Principle:


Dispersed heat provides as reference for the amount of gas-molecules passing by → direct mass-flow measurement

Advantages:

Unaffected by pressure and temperature changes, very low pressure drop, precise even at low flow rates, reference sensor can be used to provide the gas temperature.

Challenge:

A CH₄-molecule disperse a different amount of heat than a CO₂-molecule etc. Also water damp molecules disperse heat.



BINDER

BINDER Gas analysis



BINDER

Analyzer station **COMBIMASS® GA-s Hybrid**

The New flexible modular analyzer system:

- flexibility in cabinet sizes & material
- flexibility in size of graphic display
- flexibility in gas cells
- flexible for indoors/outdoors
- flexible in sampling frequency and sequence (continuously/ frequently)
- **Easy assembly and maintenance**



Modular System for specific customer's requirement

Energy Measurement



Denmark – Energy Measurement

Tax options for biogas plants

- Based on energy measurement
- Based on max. possible output



→ Energy measurement is clearly in favor

But: whole measurement must be ***better than 3% accurate***

GA-s hybrid for energy measurement

- One single sampling point in combination with one CH₄ gas module
- Implementation of thermal dispersion gas flow meter (with integrated humidity correction for the measurement of dry biogas flow), Automatic correction for actual gas composition
- Automatic correction of gas composition based on ambient atmospheric pressure and gas temperature
- **Calculation of energy contents** in the gas based on gas flow and gas composition with an overall **accuracy of better than 3%**
- Various alarm settings and transfer to the PLC possible, direct wiring via Ethernet, external access as well as data transmission/"life-bit" function via GSM/GPRS
- Auto-calibration function
- Gas feed-back from analyzer into the gas pipe possible

BINDER

GA-s hybrid for energy measurement

...see the real product on the exhibition table



Conclusions



BINDER

Conclusion

- Importance of Plant Monitoring
- Suitable solution for particular requirements
- Maintenance made easy

→ ***stable, safe*** and ***profitable*** operations



Contact



Jan Talkenberger
Manager International Sales
jan.talkenberger@bindergroup.info
+49 173 3069903
Binder GmbH
Buchbrunnenweg 18
89081 Ulm, Germany

Visit the booth
outside in the hall

